

NK Sand Kit Installation



COMPONENTS

Parts that are necessary to install the sand kit into a NK Series



- Stainer (Left)

- Stirrer (Right)

STEP 1:

Remove the pump base by removing the four screws.



STEP 2:

Once removed identify the rubber pump casing and the retainer. These will attach to the new strainer.

- Strainer, not used (left)
- Retainer (middle)
- Rubber pump casing (right)



STEP 3:

Remove **ONLY** the head bolt from the impeller.



STEP 4:

-Attach the stirrer where the head bolt was and turn until tight.

-Impeller rotation will further tighten stirrer.



STEP 5:

Place the retainer and the rubber pump casing into the sand strainer.



STEP 6:

Finally, attach the new sand strainer base to the pump with the existing hardware.

